

Subscriber Device Identification Module

404

Subscriber Controllable External
Systems Identification Module
406


Content Module
408


Layout Module
410

Content Aggregation Module
402

400

Figure 2b










Figure 5





									1
		External System Access	٧	В	A,B	•	•	•	
	Current Network Address Table	Current Network Address	192.168.abc.xyz	192.168.def.uvw	Open	•	•	•	
dentifier		Subscriber Subscriber Device Current Network ID Address	001	002	003	•	•	•	
Subscriber Identifier 246		Subscriber Name	Bob	Chris	Marvin	•	•	•	
		Subscriber ID	1234	1235	1236	•	•	•	
245			.		254	\			J

Figure 8a

Managed Eternal System(s)

External System	External System Name	Accessible System Parameters
A	Alarm System	XXXXX
В	Audio / Visual System	XXXXX
•	•	
•	•	
•	•	
×	Heating / AC System	turn heat off, turn ac off, adjust heat

Figure 8b





Figure 9a







Figure 9e







Figure 10a



Select External System

Audio / Visual

Refrigerator

4

Washer

6 Lights

Television

8 VCR

2 Heating / AC

1 | Alarm

Figure 10c

Message


Main Menu

Start

Telephone

Computer

တ



Manage Selected External

System(s)

Turn Heat On Turn Heat Off


Turn AC Off Turn AC Off Adjust Heat Adjust AC

Figure 10e

Start Message

Main Menu

Turn Alarm Off
Turn Lights On
Turn Lights Off



Audio / Visual Off

Lights Off

Selected External System(s)

Status

Heat On / 72°F

Alarm On

AC Off

Figure 10g

Start Message

Main Menu

Manage Audio / Visual Turn All Systems Off

Manage Heat
Manage Alarm
Manage Lights




Figure 11